# AD-4402

Multi-Function Weighing Indicator

Performs many operations, from batch weighing to field bus networking applications.







# AD-4402-

- ★A&D's new indicator, the AD-4402 is designed for batching operations and can also be incorporated into systems using Field Bus such as CC-Link, DeviceNet and PROFIBUS.
- \*AD-4402 has almost all the functions, user-friendly operating procedures and software you need for your weighing system.

Hopper gate control is done by forecast control mode with 1msec-high speed response.

Incorporates
Recipe and Mixing modes.



Select from 50+ functions for each of the 11 Control Inputs and 11 Control Outputs.

Meets Fieldbus requirements
by employing CC-Link,
DeviceNet and PROFIBUS.

#### **Features**


- Large and easy to see blue Vacuum Fluorescent Display (VFD).
- Uses a ten key pad and function buttons that are designed for ease of operation and understanding.
- The main display has a 7-digit VFD with 18mm tall characters.
- The subdisplay has 108, 5mm tall characters and shows the values and error comments.
- Pre-programmed with multiple sequences and functions for filling machines, simple mixing machines and other applications.

- Stores 100 data for raw materials and 100 data for recipe codes.
- RS-485 Serial Interface standard feature allows you to link up to 32 units to the display and supports the Modbus function.
- The Monitor Function shows each operating interface and provides a confirmation on the display.
- The compact body meets DIN requirements, while minimizing the depth of the indicator to 135mm.
- With the proper optional interface, the AD-4402 is compatible with CC-Link, DeviceNet, PROFIBUS.

## Multi-Function Weighing Indicator

## ●Applications●

AD-4402 can be incorporated in various applications that integrate complex systems, thereby facilitating a wide variety of sequences, such as basic filling/discharge, recipe, mixing, compensation and preliminary sequences.



## AD-4402

# Here is why we recommend our AD-4402 Multi-Function Weighing Indicator for your weighing system.

#### **★Sequential weighing mode**

The sequential weighing mode directly outputs control signals such as supply, discharge, preliminary-full-medium-dribble flow, recipe and mixing materials and nozzle control without PLC.

#### **★Interface monitoring function**

Control I/O, RS-232C,-422,-485 I/F, Current Loop, A/D converter, BCD output, Relay output, Parallel I/O, Analog output, etc. can be monitored to see if they are working correctly. You can see each interface status visually during operation without stopping the weighing system.

#### **Interface Monitoring Function**

Example: Control I/O



Input Terminals A1 to A11 Status

**Output Terminals B1 to B11 Status** 

#### **★11 Control Inputs/11 Control Outputs**

50+ functions (such as Full Flow, Over, Under, Discharge Bin, Net Display, etc.) for each of the 11 Control Inputs and 11 Control Outputs, depending on the weighing system.

#### **★Standard RS-485**

32 indicators can be hooked up to the PLC (programmable logic controller), a PC (personal computer) or other equipment that supports Modbus. This is useful for control commands input and recalling/updating the code memory.

#### **★Optional Field bus networking interface** boards for CC-Link, DeviceNet or PROFIBUS

To meet increasing requirements for networking with field bus systems, there are three bus-interface options (CC-Link, DeviceNet and PROFIBUS), which can be hooked up directly to the PLC units. More than two indicators can be hooked up to the PLC at one time.

#### **★Interactive messages**

Messages that assist current operations are shown on the display and allow anyone to operate the AD-4402 without an instruction manual. Just follow the interactive setting and operating procedures on the display. Sometimes mistakes happen. When they do, a message is displayed so you can recognize the situation and take corrective steps.

## **★Digital Span and Gravity Acceleration**Compensation

When you cannot use an actual calibration weight due to location, just input the load cell rated output voltage for zero point and full capacity calibration. After moving the calibrated weighing system, recalibrate it by inputting the local gravity acceleration value.


#### **★Calibrated A/D board**

The A/D board is calibrated before shipment and guaranteed to 1/500 accuracy. You can quickly replace the A/D board if there is a malfunction.

#### **★Safety check function**

This function is used to stop the sequence when an error or an emergency occurs. When the safety function is used, an error code is displayed and an error signal is output automatically to the PLC to stop the system. Up to eight emergency overrides can be installed.

#### **Safety Check Function** (Error Alarm Signal Output)



## AD-4402 DISPLAY

On the main and subdisplays, a Vacuum Fluorescent Display was used for easy visual recognition. Operation keys are arranged by function for easy setting and recalling the contents. What's more, there are messages for each setting and function and current status on the subdisplay. Even without an instruction manual, you can handle many emergencies.






For speedy and timely operation, keys are larger and functionally arranged.

Contents by Code and setting & status messages are displayed on the subdisplay.

Alphanumeric input is available using the setting input-keys.

### Display example

## The AD-4402's interactive, easy to see character arrangement and graphics are very user-friendly.




- The main display has 18mm tall characters and a 7-digit VFD for the weight value displays.
- The code name, code number, total, set-point, counts, bar graph and judgment can be displayed on the subdisplay.
- Displays calibration, current status (like setting procedures), error, malfunction and trouble-shooting messages.

### Rear Panel Descriptions

There are many features, like selectable I/O control terminals, standard RS-485 I/F and PLC field-bus networking interfaces such as CC-Link, DeviceNet and PROFIBUS.

- ①Load cell input  $350\Omega$  L/C up to 8 units Replacement A/D board available Accuracy guaranteed to 1/500
- ②3 Options slots Up to 3 options installed
- ③External control RS-485 standard, up to 32 units controlled simultaneously
- Programmable Control I/O Input 11 /Output 11
- ⑤AC Power 85~250V (AD-4402 only) DC 24V (AD-4402D only)



#### **Optional interface boards**




**Top Row:** DeviceNet, RS-232C and CC-Link

**Bottom Row:** RS-422/485, Analog output, and PROFIBUS

### Multi-Function Weighing Indicator

#### **Physical Dimensions**



**Specifications** 

| Analog | Input | and | A/D | Conversion |  |
|--------|-------|-----|-----|------------|--|

Input Sensitivity  $0.3\mu V/d$ Zero Adjustment Range -0mV~20mV Load Cell Excitation-DC 10V ±5% 230mA, Remote Sensing (Up to 8 load cells at  $350\Omega$ /load cell) Zero Temperature Coefficient  $\pm$ (0.2 $\mu$ V+8ppm of dead load)/°C (typically) Span temperature Coefficient ±8ppm/°C of reading (typically)

Non-Linearity 0.01% of full scale **Input Noise** Less than 0.6µVp-p Input Impedance  $10M\Omega$  or more A/D Conversion method -Delta Sigma

A/D Resolution 1,000,000 counts Maximum display resolution 16,000 counts (This limitation can be bypassed)

100 times/sec. A/D Conversion rate

**Digital Section** 

Main Display Blue Fluorescent, 7-segment, 7-digit Character Height: 18mm Blue Fluorescent, 7-segment (54 digits) Subdisplay -/5×7 dots (54 digits)

Character Height: 5mm Status Displays/Symbols — -8 displays/10 symbols (5×7 dots)

**External Input/Output Section** 

Inputs 11/Outputs 11 Control I/O Standard Serial I/F (Ch.1) — -RS-485 (Terminal) Standard Serial I/F (Ch.2) ——Current loop (Terminal) General **Power** 

AD-4402D DC 24V +10 1/2 1/5 1/5 Consumption -Approximately 30VA Operating Temperature --5~+40°C (23°F~104°F) **Operating Humidity** Less than 85% RH (non-Condensing) **Physical Dimensions**  $192(W) \times 135(D) \times 96(H) \text{ mm}$  $7.56(W) \times 5.31(D) \times 3.78(H)$  inches With terminal posts:  $192(W) \times 177(D) \times 96(H) \text{ mm}$  $7.56(W) \times 6.97(D) \times 3.78(H)$  inches **Panel Cutout Dimensions**  $186(W) \times 92(H) \text{ mm}$  $7.32(W) \times 3.62(H)$  inches Net Weight -Approximately 1.8 kg / 4.0 lb

AD-4402 AC 85V~250V (50/60Hz)

**Options** 

| o p a c i i i |                      |
|---------------|----------------------|
| OP-01         | —Parallel BCD Output |
| OP-02         | Relay Output         |
| OP-03         |                      |
| OP-04         | RS-232C I/O          |
| OP-05         | —Parallel I/O        |
| OP-07 —       | — Analog Output      |
| OP-20         | —CC-Link Interface   |
| OP-21         | —DeviceNet Interface |
| OP-22         | —PROFIBLIS Interface |

Specifications subject to change for improvement without notice.



#### ..Clearly a Better Value

A&D Company, Limited 3-23-14 Higashi-Ikebukuro, Toshima-ku, Tokyo 170-0013 JAPAN Telephone: [81] (3) 5391-6132 Fax: [81] (3) 5391-6148

http://www.aandd.ip

**A&D Engineering, Inc.** 1756 Automation Parkway, San Jose, CA 95131 U.S.A. Telephone: [1] (408) 263-5333 Fax: [1] (408) 263-0119

A&D Australasia Pty Ltd.

32 Dew Street, Thebarton, South Australia 5031 AUSTRALIA Telephone: [61] (8) 8301-8100 Fax: [61] (8) 8352-7409

A&D Instruments Ltd.

Unit 24/26 Blacklands Way Abingdon Business Park, Abingdon, Oxon OX14 TDY UNITED KINGDOM Telephone: [44] (1235) 550420 Fax: [44] (1235) 550485

(German Sales Office)

Hamburger Straße 30 D-22926 Ahrensburg, GERMANY Telephone: [49] (0) 4102 459230 Fax: [49] (0) 4102 459231

A&D Korea Limited

Manhattan Bldg. 8F, 36-2 Yoido-dong, Youngdeungpo-gu, Seoul, KOREA Telephone: [82] (2) 780-4101 Fax: [82] (2) 782-4280

**A&D RUS Co., Ltd.**Vereyskaya str.17, Moscow, 121357 RUSSIA, Telephone:[7](495) 937-33-44 Fax:[7](495) 937-55-66

#### A&D Instruments India Private Limited

509 Udyog Vihar Phase V Gurgaon-122 016, Haryana, INDIA Telephone: [91] (124) 471-5555 Fax: [91] (124) 471-5599